


## Data sheet | Item number: 870-436

Push-in type jumper bar; insulated; from 1 to 6; Nominal current 18 A; light gray

[www.wago.com/870-436](http://www.wago.com/870-436)



### Data

#### Electrical data

#### Ratings per IEC/EN 60664-1

Rated current	18 A
---------------	------

#### Approvals Ex

Rated current (Ex e II)	13.5 A
-------------------------	--------

#### Geometrical Data

Width	29 mm / 1.142 inch
Depth	2.5 mm / 0.098 inch

#### Material Data

Color	light gray
Fire load	0.03 MJ

Subject to changes. Please also observe the further product documentation!

WAGO Kontakttechnik GmbH & Co. KG  
Hansastr. 27  
32423 Minden  
Phone: +49571 887-0 | Fax: +49571 887-169  
Email: [info.de@wago.com](mailto:info.de@wago.com) | Web: [www.wago.com](http://www.wago.com)

Do you have any questions about our products?  
We are always happy to take your call at +49 (571) 887-44222.



Weight	2.1 g
--------	-------

---

### Commercial data

Packaging type	BOX
Country of origin	DE
GTIN	4044918508643
Customs Tariff No.	85366990990

---

### Counterpart

#### Downloads

#### Documentation

##### Additional Information

Technical explanations	Apr 3, 2019	pdf 2.1 MB	Download
------------------------	-------------	---------------	----------

---

### CAD/CAE-Data

#### CAD data

2D/3D Models 870-436	URL	Download
----------------------	-----	----------

---

#### CAE data

WSCAD Universe 870-436	URL	Download
------------------------	-----	----------

---

### Installation Notes



#### Jumpered

Subject to changes. Please also observe the further product documentation!

---

WAGO Kontakttechnik GmbH & Co. KG  
Hansastr. 27  
32423 Minden  
Phone: +49571 887-0 | Fax: +49571 887-169  
Email: [info.de@wago.com](mailto:info.de@wago.com) | Web: [www.wago.com](http://www.wago.com)

Do you have any questions about our products?  
We are always happy to take your call at +49 (571) 887-44222.



Commoning with push-in type jumper bars:

Two parallel jumper slots are accommodated in one terminal block.

Push jumper bars down firmly until fully inserted. When using multipole bars, push alternately on the right and then left side, until installed.

Push-in type jumper bars 1 – 3 – 5 – 7 or  
1 – – 4 – – 7

upon request

Subject to changes. Please also observe the further product documentation!